

**Guide for Submitting Electric Direct Access Service Requests (DASRs)  
Effective for DASRs received on or after 1/1/99**

The fields displayed in the following scenarios illustrate the values to use for the **“Type of Relationship”** and **“Pending SP Identifier”** fields of the DASR when identifying the relationships the ESP is requesting.

Additional fields are required for the Connect DASR (see CMEP Transaction Map located on the DES website: MADS.PGE.COM)

**ESP Serves as ELEC-ESP -- Other providers identified for metering relationships**

(Billing relationships are not included in scenarios)

	<b>CONNECT DASR Relationships Requested by ESP</b>	<b># of required DASRS</b>	<b>DASR Fields Identifying Requested Relationships</b>	<b>Relationship Providers at Time of Switch</b>
A	ESP serves as: Electric ESP  MDMA (other than ESP) serves as: Meter Agent	2	DASR 1: Type of Rel = ELEC-ESP Pending SP ID = ELEC-ESP D&B #  DASR2: Type of Rel = MTR-AGNT Pending SP ID = MTR-AGNT D&B #	ELEC-ESP = ESP MTR-AGNT = MDMA MTR-INST = no change MTR-OWN = no change
B	ESP serves as: Electric ESP  MDMA (other than ESP) serves as: Meter Agent  MSP (other than ESP) serves as: Meter Installer  MO (other than ESP) serves as: Meter Owner	4	DASR 1: Type of Rel = ELEC-ESP Pending SP ID = ELEC-ESP D&B #  DASR 2: Type of Rel = MTR-AGNT Pending SP ID = MTR-AGNT D&B #  DASR 3: Type of Rel = MTR-INST Pending SP ID = MTR-INST D&B #  DASR 4: Type of Rel = MTR-OWN Pending SP ID = MTR-OWN D&B #	ELEC-ESP = ESP MTR-AGNT = MDMA MTR-INST = MSP MTR-OWN = MO
C	ESP serves as: Electric ESP  PG&E serves as: Meter Agent  PG&E serves as: Meter Owner	2	DASR 1: Type of Rel = ELEC-ESP Pending SP ID = ELEC-ESP D&B #  DASR 2: Type of Rel = MTR-AGNT MTR-OWN Pending SP ID = PG&E D&B #	ELEC-ESP = ESP MTR-AGNT = PG&E MTR-INST = Defaults to PG&E MTR-OWN = PG&E

continued on next page....

**Guide for Submitting Electric Direct Access Service Requests (DASRs)  
Effective for DASRs received on or after 1/1/99**

D	ESP serves as: Electric ESP Meter Owner  MDMA/MSP serves as: Meter Agent Meter Installer	2	DASR 1: Type of Rel = ELEC-ESP MTR-OWN Pending SP ID = ELEC-ESP D&B #  DASR 2: Type of Rel = MTR-AGNT MTR-INST Pending SP ID = MDMA/MSP D&B #	ELEC-ESP = ESP MTR-AGNT = MDMA MTR-INST = MSP MTR-OWN = ESP
---	--	---	---	--

**ESP Serves One or More Relationships**

(Billing relationships are not included in scenarios)

	<b>CONNECT DASR Relationships Requested by ESP</b>	<b># of required DASRS</b>	<b>DASR Fields Identifying Requested Relationships</b>	<b>Relationship Providers at Time of Switch</b>
A	ESP serves as: Electric ESP only	1	Type of Rel = ELEC-ESP Pending SP ID = ELEC-ESP D&B #	ELEC-ESP = ESP MTR-AGNT = PG&E MTR-INST = no change MTR-OWN = no change
B	ESP serves as: Electric ESP Meter Agent	1	Type of Rel = ELEC-ESP MTR-AGNT Pending SP ID = ELEC-ESP D&B #	ELEC-ESP = ESP MTR-AGNT = ESP MTR-INST = no change MTR-OWN = no change
C	ESP serves as: Electric ESP Meter Agent Meter Installer Meter Owner	1	Type of Rel = ELEC-ESP MTR-AGNT MTR-INST MTR-OWN Pending SP ID = ELEC-ESP D&B #	ELEC-ESP = ESP MTR-AGNT = ESP MTR-INST = ESP MTR-OWN = ESP
D	ESP serves as: Electric ESP Meter Owner (not PG&E)	1	Type of Rel = ELEC-ESP MTR-OWN Pending SP ID = ELEC-ESP D&B #	ELEC-ESP = ESP MTR-AGNT = PG&E MTR-INST = No change MTR-OWN = ESP